

# Universal Setting Cable Kit



## FR - Sommaire

<b>1</b>	<b>Généralités</b> .....	<b>4</b>
1.1	Consignes générales de sécurité .....	4
<b>2</b>	<b>Utilisation et voyants de fonctionnement</b> .....	<b>4</b>
<b>3</b>	<b>Branchement d'un moteur</b> .....	<b>5</b>
<b>4</b>	<b>Kit</b> .....	<b>5</b>
<b>5</b>	<b>Adresse</b> .....	<b>5</b>

## DE - Inhalt

<b>1</b>	<b>Allgemein</b> .....	<b>6</b>
1.1	Allgemeine Sicherheitshinweise .....	6
<b>2</b>	<b>Bedien- und Anzeigeelemente</b> .....	<b>6</b>
<b>3</b>	<b>Anschluss eines Antriebes</b> .....	<b>7</b>
<b>4</b>	<b>Kit</b> .....	<b>7</b>
<b>5</b>	<b>Adressen</b> .....	<b>7</b>

## EN - Contents

<b>1</b>	<b>General</b> .....	<b>8</b>
1.1	General safety precautions .....	8
<b>2</b>	<b>Control and display elements</b> .....	<b>8</b>
<b>3</b>	<b>Connecting a motor</b> .....	<b>9</b>
<b>4</b>	<b>Kit</b> .....	<b>9</b>
<b>5</b>	<b>Address</b> .....	<b>9</b>

## IT - Indice

<b>1</b>	<b>Generale</b> .....	<b>10</b>
1.1	Avvertenze generali .....	10
<b>2</b>	<b>Descrizione del prodotto</b> .....	<b>10</b>
<b>3</b>	<b>Connessione al motore</b> .....	<b>11</b>
<b>4</b>	<b>Kit</b> .....	<b>11</b>
<b>5</b>	<b>Indirizzi</b> .....	<b>11</b>

## CZ - Obsah

<b>1</b>	<b>Úvod</b> .....	<b>12</b>
1.1	Všeobecné bezpečnostní pokyny ...	12
<b>2</b>	<b>Ovládací a indikační prvky</b> .....	<b>12</b>
<b>3</b>	<b>Připojení pohonu</b> .....	<b>13</b>
<b>4</b>	<b>Obsah soupravy</b> .....	<b>13</b>
<b>5</b>	<b>Kontakt</b> .....	<b>13</b>

# 1 General

This setting cable is used for adjustment and testing of shutters, equipped with Somfy 230 V AC motors. It is suitable for radio motors and WT motors (cable).

Ref.: 9 015 971



Supply voltage:	230 V AC 50 Hz	Environmental conditions:	Dry rooms
Output voltage:	230 V AC 50 Hz	Conformity:	EN 61439-1
Current output:	max. 4 A	Measurements (W x H x D):	7 x 3 x 14 cm
Protection class:	II, looped through PE connection	Weight:	567 g (incl. cable)
Degree of protection:	IP 40	Pollution degree:	1
Operating temperature:	- 10 ° C bis + 50 ° C	Environment:	B

## 1.1 General safety precautions



Prior to use the setting cable has to be checked for damage!  
Faulty setting cables must not be used.



Neutral wire can carry voltage if the mains plug will be connected.  
Remove the mains plug before connecting or disconnecting the motor to the clamp terminal



Please follow the manual of the respective motor!




Only 1 motor should be connected to the setting cable at one time  
(exception: electronic WT motors).

## 2 Control and display elements

Shines yellow, if setting cable is connected to power supply.

Push button for UP and DOWN drive of the motor; no function for RTS/io.



Shines red, if RTS/io motor is connected to power supply, push button ▲ ① activated.

① Push button for RTS/io motors only; connects RTS/io motor with power supply (▲ terminal).

② Push button for electronic motors (WT) only. Access and exit of programming mode. Both running directions are provided with power supply. Please follow the manual of the WT motor. Push button with no function on radio motors (RTS/io).



The push buttons ▲ ① and ▲ ② must **not** be activated with the following motors: LS, LT, LT PA, Orienta motors, J41TN/2TN/HTM (damage can be caused to!).

### 3 Connecting a motor


Connecting the motor directly ❶ or by the adapter cable  
Art. No. 9 015 951❷ (contained in the scope of supply).

Ⓛ Earth wire green/yellow

N Neutral wire blue

▲ UP-movement black

▼ DOWN-movement brown  
**When connecting a radio  
motor (RTS/io), this termi-  
nal remains blank!!**



**Don't use the setting cable for permanent operation of the motor. It has to be removed after completion of adjustment!**

### 4 Kit

The Kit 9 015 971 (EN) / 9 016 772 (CH) contains:

1 Setting cable USC - 9 015 577

1 Adapter cable PASS S - 9 015 951

1 Installation guid - 5 064 640

### 5 Address

#### Somfy Ltd.

Moorfield Road

Yeadon

Leeds

West Yorkshire - LS197BN

Tel. +44 1 13 39 13 03 03

e-mail: sales@somfy.com

Before installation, please read and follow these instructions. An incorrect installation can lead to serious injury. A declaration of conformity is available at [www.somfy.com/ce](http://www.somfy.com/ce) („Universal Setting Cable Plug“ & „Adaptercable PASS S“).

Subject to technical modifications.

# Somfy Worldwide

Argentina  
Somfy Argentina  
Tel: +54 (0) 11 47 37 37 00

Australia  
Somfy PTY LTD  
Tel: +61 (0) 2 88 45 72 00

Austria  
Somfy GesmbH  
Tel: +43 (0) 6 62 62 53 08

Belgium  
Somfy Belux  
Tel: +32 (0) 27 12 07 70

Brasil  
Somfy Brasil LTDA  
Tel: +55 (0) 36 95 35 85

Canada  
Somfy ULC  
Tel: +1 (0) 90 55 64 64 46

China  
Somfy China Co Ltd  
Tel: +86 (0) 21 62 80 96 60

Cyprus  
Somfy Middle East  
Tel: +357 (0) 25 34 55 40

Czech Republic  
Somfy Spol s.r.o.  
Tel: +420 (0) 2 67 91 00 07

Denmark  
Somfy AB Denmark  
Tel: +45 (0) 65 32 57 93

Finland  
Somfy AB Finland  
Tel: +358 (0) 9 57 13 02 30

France  
Somfy France  
Tel: +33 (0) 4 50 96 70 96

Germany  
Somfy GmbH  
Tel: +49 (0) 74 72 93 00

Greece  
Somfy Hellas  
Tel: +30 (0) 21 06 14 67 68

Hong Kong  
Somfy Co. Ltd  
Tel: +852 (0) 25 23 63 39

Hungary  
Somfy Kft  
Tel: +36 (0) 6 18 14 51 20

India  
Somfy India PVT Ltd  
Tel: +91 (0) 11 46 11 11 55

Indonesia  
Tel: +62 (0) 2 17 19 36 20

Italy  
Somfy Italia s.r.l  
Tel: +39 (0) 24 84 71 84

Japan  
Somfy KK  
Tel: +81 (0) 4 54 75 07 32

Lebanon  
Somfy Lebanon  
Tel: +961 (0) 1 39 12 24

Malaysia  
Tel: +60 (0)3 228 74743

Mexico  
Somfy Mexico SA de CV  
Tel: +52 (0) 55 47 77 77 70

Morocco  
Somfy Maroc  
Tel: +212 (0) 22 95 11 53

Netherlands  
Somfy BV  
Tel: +31 (0) 2 35 54 49 00

Norway  
Somfy Nordic AB  
Tel: +47(0) 41 57 66 39

Poland  
Somfy SP Z.O.O  
Tel: +48 (0) 2 25 09 53 00

Portugal  
cf. Somfy Spain  
Tel: +351 (0) 2 29 39 68 40

Russia  
Somfy LLC  
Tel: +7 (0) 49 57 81 47 72

Singapore  
Somfy PTE LTD  
Tel: +65 (0) 63 83 38 55

Slovakia  
Somfy spol. s r.o., org. zložka  
+421 (0) 3 37 71 86 38

South Korea  
Somfy JOO  
Tel: +82 (0) 25 94 43 33

Spain  
Somfy Espana SA  
Tel: +34 (0) 9 34 80 09 00

Sweden  
Somfy Nordic AB  
Tel: +46 (0) 40 16 59 00

Switzerland  
Somfy A.G.  
Tel: +41 (0) 4 48 38 40 30

Taiwan  
Somfy Taiwan  
Tel: +886 (0) 2 85 09 89 34

Turkey  
Somfy EV Otomasyon Sistemleri  
LTD STI  
Tel: +90 (0) 21 66 51 30 15

United Arab Emirates  
Somfy Gulf  
Tel: +971 (0) 48 83 28 08

United Kingdom  
Somfy LTD  
Tel: +44 (0) 11 33 91 30 30

United States  
Somfy Systems Inc  
Tel: +1 (0) 60 93 95 13 00